


Wiring Diagram: Master/Satellite Connections for all 3000 Electronic, Truck and 700,800,900 (DEF) Dispensers (only for a maximum of one Diesel and one DEF).

Notes For Master/Satellite Wiring Diagram:

1. Field connection =  (Used only with optional J-Box)
2. All wiring must be installed and used in accordance with the national electrical code (NFPA #70, Automotive and marine service code NFPA #30A), State and Local electrical codes.
3. All wiring gauge is minimum required, stranded wire with THHN Insulation must be used. Do NOT reuse old wire from an existing installation.
4. Use only rigid metal conduit. Do not use PVC conduit.
5. Rewire the LPS Satellite to match the wiring diagram below.
6. Exclusive Operation: The operator can only fill either the Master tank or the Satellite tank at one time.
7. Simultaneous Operation: A operator can fill both the Master tank and Satellite tank at the same time.

Bennett Pump Company
 Toll Free: 800-235-7618
 Telephone: 231-798-1310
 www.bennettpump.com
 Instr.# 135045
 Rev Level: A
 Date: 6-20-17

